

A1 Auto Diagnostic Scanner

User's Manual






(Android Version)



Directory:

- 1. Packing List**
- 2. How to connect device and notice**
- 3. How to install software**
- 4. How to register**
- 5. How to use**

1. Hardware Packing List

Items	Name	Qty
	Bluetooth Diagnostic Device	1
	16Pin F - 232 cable	1
	12V DC	1
	USB Cable	1
	CD	1
	Manual	1
Remark:		

2. How to connect device and Notice



Notice:

- (1) must be select mobile phones with Android operating system that with Google certification (Recommended to use : <http://www.android.com/devices/>) ;
- (2) Phone memory or SD card memory must be more than 1G;
- (3) Android operating system must be V2.3 or above V2.3;
- (4) Bluetooth communication protocol must be a standard communication protocol for Android.

3. How to install software

3.1 Put software into mobile phone from CD or download software from internet:

(1) Put CD into CD-ROM of your pc or laptop, open it and copy file named “APK” into memory card of mobile phone;

(2) Download software from website:

Steps 1: Open IE Explorer and visit <http://www.adsscan.com>

Steps 2: Click the English language to visit the English version of our official website. (Figure 01)



Figure -01

Steps 3: If it is the first time for you to use this product you should register to be our member firstly in the user area. (Figure 02), click the “register” button you will enter the following interface (Figure 03),



Figure -02

Figure -03

Steps 4:

Fill in all the needed information and click the “continue” button you will see the interface as figure 04.

(★“User Name must be use English letter and Passwords should not exceed 10 digits)




Figure -04

Steps 5: Login with Username" and "Password" previously registered;



Figure -05

Steps 6: Click “download and install software”, and enter 9 digits Product Series Number, you can find it on manual or package (Figure-06)




Input product serial no.

Input product serial no. :

Next step

Figure -06

Steps 7: Find file “adsscan(en).apk” in the list, (figure-07)



Input product serial no.

Installation list		
File Name	File Size (KB)	Date Posted
adsscan(en).rar	55550	2012/9/6 8:51:25
ADS-1(WindowsXP EnV003.42).zip	48430	2012/9/5 10:32:35
A1(EnV001.01).rar	41580	2012/9/5 8:59:15
		2012/8/22

Figure -07


Steps 8: Click “adsscan(en).apk” and download it, unzip it to your PC,(Figure-08)



3.2 Software installation:

16:20


Clock	S Planner	Music	Internet	Camera
Navigation	Email	Gallery	Search	139Mail
My files	Videos	AllShare	Kies air	Navigator
MM	Fetion	Voice recorder	Social Hub	Settings
RenRen	Weibo	Photo editor	Monternet	10086.cn
Phone	Contacts	S Memo	Messaging	Home




Steps 2: Open “My files” and find the “APK”, and find “adsscan(en).apk”


Steps 3: It shows you “install blocked” after Click “adsscan(cn).apk”, because the software is developing by ADS Tech, not from official android software market

Steps 4: Click “Settings”







Steps 5: Click “Unknown sources” allow installation of non-market applications, then it show following interface.



Steps 6: Click “OK” and following interface be showed. Please mark it.




Steps 7: Return to previous interface and click “adsscan(en).apk” again,
It shows following interface.




Steps 8: Select “Install” and it is in installation processing as the following.



Steps 9: Install finish and show “Application installed”



Steps 10: You can find A1 software in the application list as the following



4. How to register


4.1 Bluetooth Match

Steps 1: Connect A-1 Bluetooth Diagnostic Device to external power supply. To ensure that the Bluetooth Diagnostic Device power indicator lights;

Steps 2: Open mobile phone




Steps 3: Enter Settings




Steps 4: Select “WLAN settings”




Steps 5: Select “Bluetooth”




Steps 6: Turn on Bluetooth and click “search for devices”, it should find “ADS” Bluetooth device. They are Petrol Device: “ADS” or Diesel Device: “JBM-242”




Steps 7: Click the ADS Device that be find and enter passwords 1234 start to match.




Steps 8: It shows match successfully



Steps 9: Return back to application interface and find A1 diagnostic software.



Steps 10: Click“A1 Diagnostic Software”



Home interface shows “Scan”, “Manual”, “Version” and “Register”


Scan: To diagnostic vehicle

Manual: Introduction of installation, register and how to use device


Version: Information of Bluetooth Hardware and software

Register: New customers have to register and match Bluetooth device before using.


Steps 11: Click “Connect to connector” to connect Bluetooth diagnostic device



Steps 12: Select connection type. “Serial Port” or “Bluetooth”




Steps 13: Select “Bluetooth” as connection way. It shows “ADS” Bluetooth device that has been matched.




Steps 14: Select ADS device and connection successful.

4.2 Software register

Steps 1: After matching successfully, Open software and click “Register”



Steps 2: It shows “Product SN”, “Random Code” and “Registry Passwords”



Steps 3: Enter user name and password below

A1 SCANNER

Product SN: 171345710
Random Code: DMZIIBRZVH
Registry Password:

Verify

User Login

User Name:
Password:

Login **Register**

Latest Bulletin

- ADS-1 software update notice(SAAB V001.03) 2010/11/8
- ADS-1 software update notice(HYUNDAI V002.46) 2010/10/25
- ADS-1 software update notice(SAAB V001.02) 2010/10/25

CONTACT US

SKYPE ONLINE

MSN ONLINE

Steps 4: After login successfully, click “Verify” to get “Registry Password”

A1 SCANNER

Product SN: 171345710
Random Code: DMZIIBRZVH
Registry Password:

Verify

ADS
Automobile Diagnostic Scanner

User Login

Welcome : liuming

- Download install software
- Download DEMO software
- Get password
- Correct personal information
- Logout

Latest Bulletin

CONTACT US


SKYPE ONLINE

MSN ONLINE


What we do

- About u
- A top-ra
- About C

Steps 5: Enter “Product SN”, “Random Code” to get password interface,
click to get passwords




Steps 6: After getting passwords, enter passwords and click “Verify” to
finish register.



PassWord : 3021938308




Steps 7: “Registration verified” and register finish.



5. How to use

1. Turn off ignition, find the diagnostic socket, and connect A1 Bluetooth Diagnostic Scanner to the socket. Normally the socket is under the dashboard. Turn on ignition.




Notice: If the power light is not work after plugging into the socket, please do following to find problem.

- (1) Bluetooth device if insert the diagnosis socket completely.
- (2) If the ignition turn on;
- (3) The battery voltage if above 11.5V;
- (4) To measure if has voltage output from socket using multimeter, and not less than 11.5V
- (5) Measure ground feet pin 4 and Pin 5 using multimeter, make sure one of them is work;
- (6) Test all above if still not work, please contact us.


Turn on your phone, match Bluetooth diagnostic device to phone, follow

(following 4.**Bluetooth Match**, page 15-22)


2.Open “A1 Diagnostic Software” click “Scan” to start diagnostic.



3. Click vehicle to start diagnostic




4. Click China vehicle.




5. Click “DEMO” program




6. Click “01.DEMO”, it shows you what connector to select.



7. Click “OK” to enter diagnostic interface.




8. Click “Read ECU Version”, get ECU version information.




9. Click “Read trouble code” to get fault code and definition from vehicle.


Repair cars following explanation of the fault code.




10. Click “Clear trouble cod” to clear all fault code. Do you clear DTC?



11. Click “OK” and fault codes are cleared



12. Click “Read data stream”, it start to read all information from sensors and electronic equipment and systems. Click “Select All”




13. Return back after clicking “select all”. Data stream be display as following.



Read data stream	
1. Fault Code	41
2. Inlet temperature voltage	41.00 V
3. Water temperature sensor voltage	41.00 V
4. Targer idle motor position	41
5. Throttle voltage	41.00 V
6. Running time	41 s
7. Spark advance angle	...

14. Click “Read system status” get all actuator working status.



Read data stream	
1. Fuel close loop control	NO
2. Oxygen sensor	LEAN
3. Ecu self learn status	DISABLED
4. Purge overflow mode	NO
5. Efficiency increase	NO
6. Reduction speed shut up oil	NO
7. Accelerate increase rich	...

15. Click “Actuator” to control ECU to change actuator status.



16. Click”1. Engine trouble lamp”, it shows “ON operation” and “OFF operation”. Click one of them to check if engine trouble lamp light to judge if it work.

